




Compass Beam Bar


Instructions for Use

For models 975VK, 929JS, 805V,
702V, 505V, 129B, 302VJ, 366S

Please note that your
specific model compass
may not look exactly like the
drawings presented here.



- 1** Loosen the knob on the leaded side of the compass by rotating counter-clockwise. Gently pull the lower section of the leg out from the upper section.



- 2** Insert end of beam bar into hole that leg section was removed from. Tighten adjustment knob by rotating clockwise.
- 3** Insert compass leg section into hole on bottom of beam bar head. Tighten adjustment knob by rotating clockwise.